

SERVICE REQUIREMENTS



HYBRID VEHICLES

(Vehicle Production From January 2012~)

I = INSPECT AND CLEAN AS NECESSARY **R** = REPLACE
R* = RECOMMENDED REPLACEMENT AT THIS INTERVAL
S = SAVE **L** = LUBRICATE **T** = TIGHTEN TO SPECIFIED TORQUE

KEY ‡ ADJUST AS NECESSARY / ▣ DEALER MAY RECOMMEND REPLACEMENT IF UNABLE TO CLEAN. CUSTOMER PAY ITEM

A	Brake pedal and parking brake / EPB operation ‡	I	A	Transmission fluid (visual leak inspection)	I	
	Air conditioning system operation	I		Rear diff fluid AWD models (visual leak inspection)	I	
	Electrical equipment operation (lights, wipers etc)	I		Exhaust system and mountings	I	
	Electronic Health Check - Toyota diagnostic computer (GTS)	S		Body and under body / chassis condition	I	
	Spare tyre condition & pressure / repair kit expiry date	I		Valve clearance (sensory method)	I	
	Auxiliary battery - security, health check	I		Torque all wheel nuts	T	
	HV battery cooling intake filter	I		B Brake fluid (DOT3 or DOT4)	R	
	Security of HV battery mount bracket - Prius Prime only	I		C Spark plugs (Iridium type) Replace at specified Kms only, unless included in Service Plan	R*	
	Fuel tank cap, lines and connections	I			ECVT fluid	R*
	Cabin air filter ▣	I			Rear diff fluid (AWD models)	R*
	Check brake fluid level	I		D Air Filter Element	R	
	Check coolant fluid level, including Inverter coolant	I		E Coolant including Inverter Coolant (then every 75,000 km)	R	
	Cooling and heater system hoses	I		ROAD TEST (Verify overall performance and operation)		
	Air Filter Element ▣	I				
	Tyre condition and pressure	I				
	Wheel bearing condition	I				
	Front brake pads and discs	I				
	Rear brake linings / Disc pads - discs / drums	I				
	Brake pipes and hoses	I				
	Engine oil & filter (oil grade as recommended by TNZ)	R				
Steering wheel, linkage, rack, rubber boots	I					
Drive shaft joints and boots	I					
Ball joint and dust cover	I					
Front and rear suspension components	I					

SERVICE INTERVAL (SERVICE BY AGE OR KM, WHICHEVER OCCURS FIRST*)	VEHICLE AGE/YR	KM	RECOMMENDED	* Interval will change for severe usage, see over			
	1	15,000	A				
	2	30,000	A	+	B		
	3	45,000	A				
	4	60,000	A	+	B		
	5	75,000	A			+	D
	6	90,000	A	+	B	+	C
	7	105,000	A				
	8	120,000	A	+	B		
	9	135,000	A				
	10	150,000	A	+	B	+	D
	11	165,000	A				
	12	180,000	A	+	B	+	C
	13	195,000	A				

Additional Service Requirements

⟨ SOME ADDITIONAL REQUIREMENTS MAYBE NECESSARY DUE TO VEHICLE USAGE ⟩

The following information outlines service requirements for irregular or severe driving conditions.

If your vehicle falls into more than one of the following categories, use the shortest timeframe to replace or inspect. If your vehicle is operating in conditions not covered in the list below, please contact the Service Manager of your Toyota store who will recommend the best service for your vehicle.

Please note: Failure to maintain the vehicle in accordance with the required service recommendations may invalidate the new vehicle warranty.

1 VEHICLES THAT ARE FREQUENTLY SUBJECT TO CONTINUOUS HIGH SPEED AND/OR HEAVY USE SUCH AS OPERATING FULLY LOADED OR FOR TOWING.

- **Engine oil and oil filter:** Replace at half the specified distance or time
- **Brake pads and discs:** Inspect at half the specified distance or time
- **Brake linings and drums:** Inspect at half the specified distance or time
- **Brake fluid:** Replace at half the specified distance or time
- **Transmission fluid and rear motor / diff fluid (where applicable):** Inspect at half the specified distance or time

2 VEHICLES THAT ARE SUBJECT TO EXTENDED PERIODS OF IDLING AND OR SLOW SPEED DRIVING. (e.g. Taxi, Courier, Security Patrol)

- **Engine oil and oil filter:** Replace at half the specified distance or time.

3 VEHICLES THAT ARE SUBJECT TO REPEATED SHORT TRIPS (Less than 10 kilometres) WHERE THE OUTSIDE TEMPERATURE IS BELOW FREEZING.

- **Engine oil and filter:** Replace at half the specified distance or time.

4 VEHICLES THAT ARE USED FREQUENTLY ON UNSEALED ROADS AND DUSTY OR MUDDY CONDITIONS.

- **Engine oil and filter:** Replace at half the specified distance or time
- **Brake pads and discs:** Inspect at half the specified distance or time
- **Brake linings and drums:** Inspect at half the specified distance or time
- **Exhaust system and mountings:** Inspect at half the specified distance or time
- **Air filter:** Inspect/clean at half the specified distance or time
- **Steering linkage, suspension joints, rubber boots:** Inspect at half the specified distance or time
- **Body and underbody/chassis condition:** Inspect at half the specified distance or time
- **Tightness of chassis/body nuts and bolts:** Inspect at half the specified distance or time

5 VEHICLES DRIVEN THROUGH WATER SUCH AS FORDING STREAMS OR FLOODED ROADS.

- **Brake operation:** Inspect immediately
- **Transmission fluid and rear motor / diff fluid (where applicable):** Check for water contamination as soon as practicable.
- **Radiator and A/C condenser:** Inspect fins are clear of debris