

SERVICE REQUIREMENTS

These requirements are for vehicles operating under normal conditions only. Refer to the Additional Maintenance Requirements and adjust the servicing as recommended for any applicable conditions.

GR YARIS GR COROLLA GR86

R = REPLACE, **S** = SAVE, **C** = CLEAN,
T = TIGHTEN TO SPECIFIED TORQUE,
I = INSPECT, CLEAN AND ADJUST AS
 NECESSARY

KEY

¤ DEALER MAY RECOMMEND REPLACEMENT IF UNABLE TO CLEAN.

A	Brake pedal and parking brake operation	I	Steering wheel, linkage, rack, rubber boots	I
	Air conditioning system operation	I	Drive shaft joints and boots	I
	Electrical equipment operation (lights,wipers etc)	I	Manual transmission oil (includes front diff GR Yaris & GR Corolla)	I
	Electronic health check - Toyota diagnostic computer (GTS+)	S	Auto trans fluid level & hoses (visual leak inspection) GR86 only	I
	Spare tyre - repair kit expiry date	I	Rear diff oil level	I
	Fuel tank cap, lines and connections	I	Propeller shaft - tightness of bolts	T
	Cabin air filter ¤	I	Exhaust system and mountings	I
	Brake fluid level (including clutch for M/T)	I	Body and under body / chassis condition	I
	Coolant fluid level	I	Torque all wheel nuts	T
	Cooling and heater system hoses	I	Brake and clutch fluid (DOT4)	R
	Drive belts	I	Rear diff oil	R
	Battery - security, health check	I	Cabin air filter - GR Yaris / GR Corolla	R
	Air filter element ¤	I	Transfer fluid - GR Yaris / GR Corolla	R
	Tyre condition and pressure	I	Air filter element	R
	Wheel bearing condition	I	Manual transmission oil (includes front diff GR Yaris & GR Corolla)	R
	Front brake pads and discs	I	Auto transmission fluid	R
	Rear brake pads and discs - park brake drums / shoes	I	Spark plugs (Iridium type). Replace at specified kms only, unless included in Service Plan	R
	Brake pipes and hoses	I	Engine / Heater Coolant (then every 75,000 km / 5 years)	R
	Engine oil & filter (GR Yaris/GR Corolla every 7,500 km)	R	Vacuum pump for brake booster (GR Yaris / GR Corolla)	I
	Ball joint and dust cover	I	ROAD TEST (Verify overall performance and operation)	
	Front and rear suspension components	I		

SERVICE INTERVAL (SERVICE BY AGE OR KM, WHICHEVER OCCURS FIRST*)	VEHICLE AGE/YR	KM	RECOMMENDED * Interval will change for severe usage, see over				
	1	15,000	A				
	2	30,000	A	+	B		
	3	45,000	A	+		C	
	4	60,000	A	+	B		
	5	75,000	A				
	6	90,000	A	+	B	+	C
	7	105,000	A			+	D
	8	120,000	A	+	B		
	9	135,000	A	+		C	
	10	150,000	A	+	B	+	E
	11	165,000	A				
	12	180,000	A	+	B	+	C
	13	195,000	A			+	D

ADDITIONAL MAINTENANCE REQUIREMENTS

GR YARIS GR COROLLA GR86

Some additional requirements maybe necessary due to vehicle usage

If your vehicle is operating in conditions not covered in the list below, please contact the Service Manager of your Toyota store who will recommend the best service for your vehicle.

1 VEHICLES THAT ARE SUBJECT TO SEVERE USAGE SUCH AS REPEATED HARD DRIVING INCLUDING TRACK/MOTORSPORT USE.

- **Engine oil and oil filter:** Inspect before and after severe/track use and replace as necessary.
- **Brake pads and discs:** Inspect before and after severe/track use and replace as necessary.
- **Brake fluid:** Inspect condition before and after severe/track use and replace as necessary.
- **Transmission, diff and transfer fluids:** Inspect/replace as necessary.
- **Steering linkage, suspension joints, rubber boots:** Inspect more frequently including before and after severe/track use.
- **Tightness of chassis/body nuts and bolts:** Inspect more frequently including before and after severe/track use.
- **Exhaust system and mountings:** Inspect more frequently including before and after severe/track use.

2 VEHICLES THAT ARE SUBJECT TO EXTENDED PERIODS OF IDLING AND / OR SLOW SPEED DRIVING.

- **Engine oil and oil filter:** Shorten normal replacement interval.

3 VEHICLES THAT ARE SUBJECT TO REPEATED SHORT TRIPS (LESS THAN 10 KILOMETRES) WHERE THE OUTSIDE TEMPERATURE IS BELOW FREEZING, OR THE ENGINE TEMPERATURE DOESN'T REACH NORMAL.

- **Engine oil and oil filter:** Shorten normal replacement interval.

4 VEHICLES THAT ARE USED FREQUENTLY IN DUSTY CONDITIONS.

- **Engine oil and oil filter:** Shorten normal replacement interval.
- **Air filter:** Inspect more frequently and shorten normal replacement interval if required.
- **Cabin air filter:** Inspect more frequently.
- **Brake discs, pads, drum, linings:** Inspect more frequently.
- **Brake fluid:** Inspect more frequently for contamination.

5 VEHICLES THAT ARE USED FREQUENTLY ON ROUGH ROADS OR MUDDY CONDITIONS.

- **Brake discs, pads, drum, linings:** Inspect more frequently.
- **Brake fluid:** Inspect more frequently for contamination.
- **Steering linkage, suspension joints, rubber boots:** Inspect at half the specified distance or time.
- **Body and underbody/chassis condition:** Inspect/clean more frequently.
- **Tightness of chassis/body nuts and bolts:** Inspect more frequently.

6 VEHICLES DRIVEN THROUGH WATER SUCH AS FORDING STREAMS OR FLOODED ROADS.

- **Brake and clutch operation:** Inspect immediately.
- **Transmission fluid:** Inspect as soon as practicable.
- **Radiator and A/C condenser:** Inspect fins are clear of debris.
- **Differential oil front and rear:** Check for water contamination as soon as practicable.